


Controlling Doors in EntraPass Go



From the side menu, press the doors icon.

You are then presented with the door status and options from left to right:

1. Back to Schedule: Set door settings to default operation.
2. Temporary Unlock: Choose a period of time for which to unlock the door. The default is ten seconds.
3. One Time Access: Opens the door once.
4. Unlock: The door will remain unlocked until you lock it again. The icon switches to the Lock icon.

You can also change the access schedule and toggle the reader on or off.